



Sequence of Operation (SOO): One function

- 1) RED AND WHITE rods are a differential function. When water level falls below WHITE rod, FILL LED status indicator, power relay, and dry contact are active. When water level contacts RED rod, FILL LED status indicator, power relay, and dry contact are inactive and remain inactive until water level falls below the WHITE rod.

## WATERLINE CONTROL

### WLC 3000 - SIMPLEX WATER LEVEL FILL CONTROL

NOTE: CONTACT THE FACTORY FOR CUSTOM SENSOR REQUIREMENTS

NOTE: SEE WRITTEN SPECIFICATION FOR MORE DETAILS

AVAILABLE FROM  
SYSTEM DYNAMICS, INC.

888-905-1892