Waterline Controls® LEVEL INDICATOR



No Moving Parts!



The Waterline Controls Level Indicator is used to show the level of water. This keeps the user informed about the water at all times and avoids the situation of water running out when it most needed.

Waterline Controls
P.O. Box 12544
Scottsdale, Arizona 85260
Toll Free: 888-905-1892
info@waterlinecontrols.com
www.waterlinecontrols.com